

A comparison of automated detectors for tonal signals from delphinids

Julie Oswald, Kerry Dunleavy, Shannon Coates, Marie A. Roch, Doug Gillespie, David K. Mellinger



University of
St Andrews




SAN DIEGO STATE
UNIVERSITY

OSU
Oregon State
UNIVERSITY

 **Bio-Waves**
Incorporated

Introduction

- Delphinid whistles
 - Long duration, tonal sounds
 - Frequency and amplitude modulated
 - Start and end points often undefined
- Automated detection and contour extraction can be challenging
 - Several different approaches



Objectives

- **Evaluate and compare performance** of three automated whistle detection and contour extraction algorithms
 - **Silbido** (Roch et al.¹)
 - **Ishmael's** tonal detector (Mellinger et al.²)
 - **PAMGuard's** whistle and moan detector (Gillespie et al.³)

¹ Roch et al. 2011, JASA 130:2212-2223

² Mellinger et al. 2011, JASA 129:4055-4061

³ Gillespie et al. 2013, JASA 134:2427-2437

Dataset

- Manually annotated whistles¹
 - *Silbido* tracing tool
 - www.mobysound.org
- Four encounters per species
 - Different SNRs and overlapping sounds

Species	Whistle characteristics	n
Melon-headed whale	Low frequency, short duration	2,253
Bottlenose dolphin	Large frequency range, long duration	1,637
Short-beaked common dolphin	High frequency, short duration, overlapping whistles	3,505

¹ Roch et al. 2011, JASA 130:2212-2223

Detector Evaluation

- Each detector was run on the same wav files and results compared to manual annotations
 - *Silbido* Scoring Tool
- Different settings used for each detector
- Chose settings that provided best balance between precision and recall

Important!!

Results may have been different if different settings had been chosen

Silbido Scoring Tool

- Compares whistle detector output to manual annotations
- Calculates five metrics:
 - Precision
 - Recall
 - Fragmentation
 - Percent coverage
 - Frequency deviation

Precision

- Measure of 'exactness'
 - Percentage of automated detections that were actually whistles
 - Aiming for 100%

$$Precision = \frac{TP}{TP + FP}$$

TP = True Positive detections

FP = False Positive detections

Recall

- Measure of 'completeness'
 - Percentage of whistles in a recording that were detected
 - Aiming for 100%



$$Recall = \frac{TP}{TP + FN}$$

TP = True Positive detections

FN = False Negative (missed) detections



Fragmentation

- Average number of detections per individual whistle
- Aiming for a value of 1





Percent coverage

- Average percentage of the duration of individual whistle contours that were extracted
- Aiming for 100%




Frequency deviation

- Absolute difference in frequency between extracted time-frequency contour and actual whistle
- Aiming for a value of 0




Results


Precision – measure of accuracy



Recall – measure of completeness




Frequency deviation




Frequency deviation

- Driven by analysis window size (to an extent)
 - 8ms window, 192 kHz sampling rate = 125 Hz frequency resolution
- Highest deviation of 124 Hz is within this window size

Percent coverage



Fragmentation



Discussion

Factors influencing detector performance


- Comparison metrics influenced by detector settings
- Examined recordings with different whistle characteristics and SNR
- All three detectors missed short whistles with low SNR
 - Likely reason for low recall scores for melon-headed whales
- Ishmael missed whistles with the lowest SNR

Factors influencing detector performance

- Other factors that affected performance of detectors
 - Presence of overlapping whistles
 - Presence of clicks and buzzes



Overlapping whistles

- Increased number of missed whistles and false positives



Presence of clicks and buzzes

- Increased number of missed whistles, false positives



What does it all mean?

- All detectors performed well and had different strengths and weaknesses
- **PAMGuard**: highest precision and recall, 😊
highest fragmentation and frequency deviation ☹️
- **Silbido**: lowest fragmentation, highest % coverage 😊
 - New version of *Silbido* – higher precision and recall
- **Ishmael**: lowest frequency deviation, 😊
lowest recall ☹️

What does it all mean?

- Choice of detector depends on analysis goals
 - Detection only?
 - PAMGuard
 - Detection and classification?
 - *Silbido*
- Important to understand detector performance
 - Groundtruth on all new datasets

Acknowledgements

- Tina Yack, Elizabeth Ferguson, Tom Norris, Bio-Waves, Inc.
- Yvonne Barkley and Roch lab
- Mike Weise, ONR
- Anurag Kumar and Bob Gisiner, LMR



